



MINIFLOW

INSTRUCTION MANUAL
MANUAL DE INSTRUCCIONES

MINIFLOW


The MINIFLOW machine is an excellent small but powerful confetti blower. It becomes ideal on parades, catwalks and other shows.

TECHNICAL SPECIFICATIONS

REF : M-FLOW
SIZE : 80 X 20 X 30 cm
WEIGHT : 8 KG
VOLTAGE IN : 220-240V 50 HZ
NOMINAL POWER : 900W
FUSE : 5A.

PARTS

1. On/off switch
2. Output tube
3. Confetti feeding tube
4. Output tube thread
5. Suction hose
6. Tripod support
7. Fixing knobs
8. Power cable
9. Fuse



ASSEMBLY AND OPERATION

1. Loosen the fixing knobs (7), open the foot tripod support (6) so that to form a “V” shape with the steel legs, and re-tighten the fixing knob. Place the machine on a flat and stable surface. You can also fix the machine in a tripod stand using a stand adaptor (not included). In this case, open the tripod support (6) so that the biggest leg is in the fully upright position and the small leg gets horizontally from the rear of the machine. Insert then the stand adaptor through the hole of this bigger leg to hang the Miniflow machine on a tripod stand
2. Thread the OUTPUT TUBE (2) in the thread for the output tube (4).
3. If you need to feed the machine at a distance, insert the suction hose (5) to the confetti feeding tube (3).
4. Connect the power cable (8) to a power source or other power control.
5. Turn On the machine by pressing the on/off switch (1) and insert slowly and regularly through the confetti feeding tube (3) or the suction hose (5). If you have the machine fixed on a tripod, you will be able to feed the machine with confetti and orientate the output by rotating the machine so that to cover a wider area.

REMARKS

- It is recommended to use confetti of small or medium size in order to avoid that get stuck.
- If you want to use a long suction hose (over 2m) use then only confetti of small size such is the square confetti 6mm or 17mm
- When using confetti of large size or introducing a big amount of confetti into the machine it can get stuck. To unclog the output tube or hose, cover with your hand the output tube (2) with the machine on, and the confetti will come out instantly by the confetti feeding tube or the hose.

GENERAL CAUTION FOR MINIFLOW

- MINIFLOW machine has been designed for the effect described. Any other use, different from the written excludes Oh!FX (OH FX ENTERTAINMENT, SL) of liability and warranty.
- In case of malfunction, do not attempt to disassemble the machine and contact the distributor or manufacturer. Any manipulation may exclude the warranty
- Use only the consumables intended for that specific use, and duly certified.
- Only one adult and qualified person must manipulate the machine.

MINIFLOW


La máquina MINIFLOW es una excelente sopladora de confeti ideal para fiestas y espectáculos de formato pequeño.

ESPECIFICACIONES TÉCNICAS

REF : M-FLOW
TAMAÑO : 80 X 20 X 30 cm
PESO : 8 KG
ALIMENTACIÓN : 220-240V 50 HZ
POTENCIA NOMINAL : 900W
FUSIBLE : 5A

PARTES

1. Interruptor
2. Tubo de salida
3. Alimentación de confeti
4. Rosca para tubo de salida
5. Manguera de aspiración
6. Pies soporte
7. Pomos de fijación
8. Cable de alimentación
9. Fusible



MONTAJE Y OPERATIVA

1. Afloje los pomos de fijación (7), abra los pies de soporte (6) en forma de V por debajo del cuerpo de la máquina y vuelva a apretar los pomos de fijación. Coloque la máquina en una superficie plana y estable. También puede ubicar la máquina en un pie de altavoz mediante el soporte “vaso para pie” (no incluido). En este caso abra los pies de soporte (6) de manera que el más grande quede en posición totalmente vertical y el pequeño en horizontal por la parte trasera de la máquina. Fije el vaso para trípode en el pie de soporte vertical e insértelo en el pie de altavoz.
2. Enrosque el tubo de salida (2) en la rosca para tubo de salida (4).
3. Si necesita alimentar la máquina a distancia inserte la manguera de aspiración (5) a la toma de alimentación de confeti (3).
4. Conecte el cable de alimentación a una toma de corriente.
5. Ponga en marcha la máquina accionando el interruptor (1) y vaya introduciendo el confeti poco a poco por la toma de alimentación de confeti (3) o la manguera de aspiración (5). Si tiene la máquina colocada en trípode puede ir alimentándola de confeti con una mano mientras va girando la máquina con la otra mano para cubrir más espacio.

OBSERVACIONES

- Se recomienda utilizar confeti de formato mediano / pequeño.
- Si utiliza una manguera de aspiración larga (más de 2m) utilice sólo confeti de tamaño pequeño.
- Si se utiliza confeti de tamaño grande o se introduce mucha cantidad de confeti a la máquina ésta puede atascarse. Para deshacer el atasco tape momentáneamente la salida del confeti de la máquina con una mano sin apagar la máquina. El atasco de confeti saldrá al instante por la toma de alimentación.

PRECAUCIONES

- La máquina MINIFLOW ha sido diseñada para el efecto descrito. Cualquier otro uso excluirá a Oh!FX (OH FX ENTERTAINMENT,SL) de toda responsabilidad y garantía.
- Si detecta un mal funcionamiento deje de utilizar la MINIFLOW, desconéctela y contacte con su distribuidor. Cualquier manipulación invalidará la garantía.
- Utilice sólo los consumibles previstos para este uso y debidamente certificados.
- Solo una persona adulta y cualificada debe manipular la máquina.



www.ohfx.eu

