



COLOR MIXER

INSTRUCTION MANUAL

MANUAL DE INSTRUCCIONES

COLOR MIXER

COLOR MIXER is an accessory for Oh!FX foam machines that allows you to change the foam color quickly, cleanly and conveniently during setup or operation. Its quick-connect system makes installation easy, and its four suction lines allow you to choose one color or combine several to create new tones.

DESCRIPTION

Easy installation between the machine suction line and the colored foam fluid containers. Work with a single color or mix several colors to obtain new shades. The suction lines include a filter (4) and a non-return valve (2).


TECHNICAL SPECIFICATIONS

REF: **COLMIX**
Size: **21,5 x 7,3 x 9,5cm**
Tube size: **2m**
Weight: **1,5 Kg**

EAN: **8436569944257**

PARTS

1. Foam mixer taps
2. Non-return valves
3. Suction tubes
4. Filters
5. Outlet tube
6. Male quick connector
7. Female quick connector



BASIC INSTALLATION




Fig. 1




Fig. 2




Fig. 3 / 4

1. Place the color selector at the base of the machine, on the side where the foam fluid suction tube exits. The selector is fixed in place by magnets.
2. Cut the machine's main foam fluid suction tube approximately 20 cm from the machine, as shown in Fig. 2.
3. Insert the female quick connector (7) into the section of tube that remains connected to the machine, as shown in Fig. 3.
4. Insert the male quick connector (6) into the other cut section of tube so that both ends can be reconnected whenever you do not want to use the color selector. Keep that spare tube section.
5. Connect the male quick connector (6) of the selector outlet tube (5) to the female quick connector (7) of the machine suction tube. Fig. 5.




Fig. 5

SET UP AND OPERATION

1. Place the suction tubes (3), each with its filter (4), into containers filled with colored foam fluid ready for use.
2. Check that all foam mixer taps (1) are closed. The handle must be perpendicular to the suction tube.
3. Start the Foam machine in the usual way.
4. Open the foam mixer tap (1) for the desired color.
5. To obtain new tones, you can open more than one foam mixer tap (1) and mix colors.

RECOMMENDATIONS

- Check that the tubes (3) and quick connectors (6) and (7) are fully inserted before starting the machine.
- Always use clean foam fluid that is ready for use.
- When finished, close all foam mixer taps (1) and remove the suction tubes (3) from the containers with the machine stopped.
- Do not use metal clamps to secure the quick connectors to the hose. They could cut or damage the hose.

COLOR MIXER

COLOR MIXER es un accesorio para las máquinas de espuma Oh!FX que permite cambiar el color de la espuma de forma rápida, limpia y cómoda durante el uso. Su sistema de conexiones rápidas facilita la instalación, y sus cuatro líneas de aspiración permiten seleccionar un color o combinar varios para crear nuevas tonalidades.

DESCRIPCIÓN

Instalación sencilla entre la aspiración de la máquina y los recipientes de líquido espumógeno coloreado. Permite trabajar con un solo color o mezclar varios colores para obtener nuevos tonos. Los tubos de aspiración incorporan filtro (4) y válvula antirretorno (2).

ESPECIFICACIONES TÉCNICAS

REF: **COLMIX**

Tamaño: **21,5 x 7,3 x 9,5cm**


Tamaño tubos: **2m**

Peso: **1,5 Kg**

EAN: **8436569944257**

PARTES

1. Llaves de paso
2. Válvulas antirretorno
3. Tubos de aspiración
4. Filtros
5. Tubo de salida
6. Conector rápido macho
7. Conector rápido hembra



INSTALACIÓN




Fig. 1




Fig. 2




Fig. 3 / 4

1. Coloque el selector de colores en el pie de la máquina, en el lado por el que sale el tubo de aspiración del líquido espumógeno. El selector queda fijado mediante imanes.
2. Corte el tubo de aspiración de líquido espumógeno de la máquina a unos 20 cm, como se indica en la fig. 2.
3. Inserte el conector rápido hembra (7) en el tramo del tubo que permanece conectado a la máquina, tal como se muestra en la fig. 3.
4. Inserte el conector rápido macho (6) en el otro tramo del tubo que ha cortado para poder volver a unir ambos extremos cuando no desee utilizar el selector de colores. Reserve ese tramo de tubo sobrante.
5. Conecte el conector rápido macho (6) del tubo de salida (5) del selector al conector rápido hembra (7) del tubo de aspiración de la máquina. Fig. 5.




Fig. 5

OPERATIVA

1. Introduzca los tubos de aspiración (3), cada uno con su filtro (4), en recipientes con líquido espumógeno coloreado y listos para usar.
2. Compruebe que todas las llaves de paso (1) estén cerradas. La manecilla debe quedar perpendicular al tubo de aspiración.
3. Ponga en marcha la máquina de espuma de la forma habitual.
4. Abra la llave de paso (1) correspondiente al color deseado.
5. Si desea obtener nuevas tonalidades, puede abrir más de una llave de paso (1) para mezclar colores.

RECOMENDACIONES

- Compruebe que los tubos (3) y los conectores rápidos (6) y (7) queden bien insertados antes de la puesta en marcha.
- Utilice siempre líquido espumógeno limpio y preparado para su uso.
- Al terminar, cierre todas las llaves de paso (1) y retire los tubos de aspiración (3) de los recipientes con la máquina parada.
- No utilice abrazaderas metálicas para fijar los conectores rápidos al tubo. Podrían dañar o cortar el tubo.

